

Hemodynamic Monitoring in Critical Care Transport

Mike Watkins
MPA, RN, FP-C
VCUHS

Overview

- ▶ Introduction to Hemodynamic Monitoring
 - How it applies to CCT
 - Patient population and clinical conditions
 - "Sickest of the sick"
- ▶ Types of Monitoring
- ▶ Systems and Equipment setup

Overview

- ▶ Hemodynamic Waveforms
 - Basic interpretation and differentiation
- ▶ Vasoactive agents and effects on Hemodynamics
 - Specific continuous infusions
- ▶ Conclusion

Hemodynamic Monitoring

- ▶ Vital signs
 - Non-Invasive and Invasive
- ▶ Patient condition determines appropriateness
 - Trending specific parameters
- ▶ Comparing Non-invasive and Invasive provides reference for quality of perfusion and circulation

Non-Invasive Measurements

- ▶ Standards:
 - Pulse
 - Pulse Oximeter
 - Blood Pressure
 - Respirations
- ▶ What do the alterations tell you?
 - Each a different facet of the big picture

Invasive Monitoring

- ▶ Variation off of the Non-invasive
 - "From within the body"
- ▶ Measurements
 - Fluid flow properties
 - Location of port
 - Blood content

Application in CCT

- ▶ Most Useful: Arterial Blood Pressure
 - Correlate to non-invasive BP, then cuff can cycle less
 - Work when cuff does not
- ▶ Helpful for titration of high potency vasoactive infusions
 - Nitroglycerin
 - Epinephrine
 - Norepinephrine
 - Esmolol

Concerns in CCT

- ▶ Placed by physicians often prior to transport
 - ED to ICU or ICU to ICU
- ▶ Potential:
 - Source of bleeding
 - Route of infection
 - Thrombus

Concerns in CCT:

- ▶ Apply to a limited patient population
 - Cardiac and surgical
 - Trends more important than a single measure
- ▶ Treat the patient, not the monitor
 - Avoid tunnel vision
 - Keep the patient safe
- ▶ "Normal" values are based on supine and healthy

Safety

- ▶ Account for everything attached to the patient
 - Transduce the lines even if the values do not make sense
 - Important to secure connections, prevent air embolus, bleeding, movement of catheter

Transport Considerations

- ▶ Location of lines and security of lines?
- ▶ Central lines verified by chest X-ray?
 - Internal Jugular
 - Subclavian
 - Swan-Ganz
 - Balloon Pump
- ▶ Copies to travel: essential!

Anatomy

- ▶ Heart
 - Atria and Ventricles
 - Coronary Arteries
 - Valves
 - Aortic and Pulmonic
 - Tricuspid (Right) and Mitral (Left)
- ▶ Pulmonary Vasculature
- ▶ Arteries
- ▶ Capillaries
- ▶ Veins
- ▶ Blood

Physiology

- ▶ Tank: blood vessels
 - Size; what has happened?
- ▶ Pump: Heart
 - Is it working? How effective?
- ▶ Fluid status: blood and hydration
 - Is the tank full?

Cardiac Cycle

- ▶ Ventricular Diastole
 - Isovolumic Relaxation: filling from sources
 - Vena cava, passive filling from pulmonary vessels
 - Closure of pulmonic and aortic valves
- ▶ Atrial Systole
 - "Kick" signals from SA to AV
- ▶ Ventricular Systole
 - Isometric contraction
 - Greatest myocardial expenditure and oxygen consumption

Stroke Volume

- ▶ Volume of blood ejected by the heart with each: 60 to 130ml
- ▶ Preload
 - End-diastolic stretch on myocardial muscle fibers
- ▶ Afterload
 - Sum of all the forces against which the muscle fibers of both ventricles must work
- ▶ Contractility
 - Inotropic state of the myocardium
- ▶ Muscular Synchrony

Invasive Monitoring

- ▶ Arterial Pressure
- ▶ Central Venous Pressure
- ▶ Pulmonary Artery Pressure
 - Pulmonary Artery Wedge Pressures
 - SWAN GANZ catheters

Invasive Monitoring

- ▶ Principle:
 - Pitot gauge or tube
 - Measures fluid flow velocity



Pressure Measurement Access Points

- ▶ Arterial lines
- ▶ Central Lines
 - Cordis: the line
 - Swan: inserted through the line
- ▶ Other pressures
 - ICP
 - Bladder



Additional Hemodynamic Parameters

- Mean Arterial Pressure
- Cardiac Output
- Cardiac Index
- Systemic Vascular Resistance
- Systemic Vascular Resistance Index


Arterial Pressure Lines

- Continuous Blood Pressure monitoring
 - “Instant” response to vasoactive agents
 - Correlate against the non-invasive blood pressure
 - Match to gauge accuracy
 - Common sites:
 - Radial Artery
 - Brachial artery
 - Femoral artery
 - Different sites may have a gradient difference

Indications: Intra-arterial Monitoring

- Critically ill or injured
- Major surgical procedures
- Major vasopressor or vasodilator support
- Intra-aortic Balloon Pump: IABP
 - Provides pressure trigger
- ICP Monitoring
- Serial Blood gas measurement
- Severe acid-base imbalance

Arterial Pressure Waveform




Waveform Qualities


- Crisp: sharp, clear lines, flowing
 - ideal
- Dampened: blunted, smooth
 - Low flow states, air in line
- Hyperdynamic: spikes
 - Pinched, compliant tubing

Patient Effects on Arterial Pressures

- Tachycardia
- Hypotension
- Atrial Fibrillation/Irregular Heart rate




Waveforms




Balloon Pump

- ▶ Every IABP transport will use these skills
- ▶ Arterial pressure wave is one of three triggers for balloon sensing
 - ECG, internal, and Pressure (Fiberoptic)
 - Ratios: 1:1, 1:2, 1:3 depending
- ▶ Evaluation of waveform
 - Improved coronary perfusion (Augmentation)
 - Afterload Reduction
 - Assisted and Unassisted flows


Balloon Pump Waveform



Balloon Pump Waveforms



Balloon Pump Waveforms



Complications of Arterial Lines

- ▶ Ischemia to extremity
 - Especially in IABP
- ▶ Hemorrhage
 - Arterial
- ▶ Degraded signal in low flow states

Transport Consideration

- ▶ Secure transducer to stretcher or tape to patient's chest at phlebostatic axis
- ▶ Verify distal, collateral circulation
- ▶ Radial artery line
 - Skin color and cap refill, ulnar pulse palpable, place pulse oximeter on finger to monitor
- ▶ Femoral (IABP)
 - Dorsal pedis and posterior tibial pulses, foot warm to touch

Mean Arterial Pressure

- ▶ CO, SVR, and CVP factors
- ▶ Formula:
 - Systolic BP+ (2 x Diastolic BP)
- ▶ Formula 2
 - $(CO \times SVR) + CVP$
 - <http://www.cvphysiology.com/Blood%20Pressure/BP006.htm>

Central Venous Pressure

- ▶ Catheter placed in large "central vein" or right atrium
- ▶ Works with large, central venous access point for fluid and medications
 - Benefits: central lines better for rapid infusions and less risk for highly concentrated medication
 - Risks: placement increases risk for infection, bleeding, and pneumothorax

Central Venous Pressure Monitoring

- ▶ Measures venous return to right atrium
 - Right atrial pressures
 - Right ventricular end-diastolic pressure
 - Correlates to the left end-diastole in healthy individuals
- ▶ Mean number; calculated from high and lows
 - "Normal" is 0 to 8mmHg
 - Critically ill often need to be higher
- ▶ Used to guide fluid resuscitation


Clinical Significance

- ▶ Elevated CVP
 - Fluid Overload
 - Poor right ventricular function (stiff, non-compliant)
- ▶ Decreased CVP
 - Dehydration
 - Poor peripheral vascular tone
- ▶ In CCT is least important of invasive monitors
 - Resource dependent
 - Other clinical signs will guide you


CVP Limitations

- ▶ Evaluate as a trend
- ▶ Systemic vasoconstriction can present a CVP elevated despite hypovolemia
- ▶ Mechanical ventilation:
 - Positive pressure ventilation increases thoracic and central venous pressures
 - Measure at end-expiration


Waveform



CVP waveform




CVP and Respirations



Complications of Central Lines

- ▶ Hemorrhage
- ▶ Vascular damage/erosion
- ▶ Arrhythmias
 - Catheter tickles the heart
- ▶ Infection: time in place
- ▶ Thrombo-embolic
 - Air embolus or thrombus of clot
- ▶ Pneumothorax

SWAN Ganz Pulmonary Artery Diagnostic Catheter




Pulmonary Artery Pressures


- ▶ Normal measures:
 - 15 to 25 systolic
 - 6 to 12 diastolic (CVP should never be lower)
- ▶ Indicator of left ventricular function and pulmonary vascular status
 - Increased in cases of COPD, ARDS, Sepsis, shock
 - Pulmonary hypertension occurring secondary to decreased left heart function
- ▶ CVP should never be lower than PAD

Pulmonary Artery Waveform


Note: "mitten" shape appearance, indicating PA placement



Swan Ganz Tip migration



Swan Ganz Tip migration



Pulmonary Artery Wedge Pressures

- ▶ Wedging is temporarily "Blocking" of the Pulmonary Artery
- ▶ "Looks" through the vasculature to the left atrium and the left ventricular end-diastolic pressure
 - Aortic valve is closed, just prior to opening
- ▶ In absence of pulmonary vascular disease, the pulmonary artery diastolic pressure equates to left atrial pressure

Inadvertent Wedge

- ▶ Recognize: the previous wave has changed
- ▶ Assess: are there any changes in patient condition?
 - All ABCs with ECG, SaO₂, and EtCO₂ if available
- ▶ Noninvasive: turn or move patient
 - Lift up head slightly, turn neck
- ▶ Contact medical control of receiving hospital
 - May advise withdrawing catheter


Pulmonary Artery Wedge Pressure

- ▶ Normal 4-12 mmHg
- ▶ Balloon inflated with 1.25 ml air, for less than 15 seconds


PA Wedge Dangers

- ▶ Creates pulmonary embolism/ischemic injury
 - Mechanical occlusion
- ▶ Over-inflation of balloon puts pressure on vessels and damages tissue
- ▶ Balloon Rupture

Swan-Ganz waves on advancement



Tour of the SWAN Ganz



Tour of the Swan Ganz



Swan through Cordis



Monitor cable for Swan

Tour of the Swan Ganz



Swan Balloon port




Syringe lock off: in line

Depth Measurement



Wedge balloon




Balloon deflated

Balloon Inflated

Cardiac Output

- ▶ Amount of blood ejected from the ventricle in a minute: 4 to 8 L
- ▶ Heart Rate X Stroke Volume
- ▶ With Swan Ganz determined CO through **Thermo-dilution**
 - Known volume of solution at known temperature
 - Injected rapid bolus through CVP port of catheter
 - "Downstream" temperature measured and the time difference calculation performed provides the cardiac output
- ▶ Cardiac Index: adjusts CO for BSI

Determining Cardiac Output: Thermo-dilution Method



Cardiac Output

- ▶ Non-invasive methods
 - Vigileo Flo-trac system
 - Uses the arterial pressure waveform
- ▶ Echocardiograph
 - Creates visual image of flow
 - Bedside, in hospital



Cardiac Output

- ▶ USCOM (Ultrasound Cardiac Output Monitor)
- ▶ Continuous Doppler Wave
- ▶ Non-invasive
- ▶ Literature NOT fully supporting device, although some correlation exists



Systemic Vascular Resistance

- ▶ Cannot be measured directly
- ▶ Computed:
 - MAP minus CVP/Cardiac Output times 80
- ▶ Use of Swan or Vigileo monitor
- ▶ Normal: 770 to 1500 dynes/sec/cm⁻⁵
- ▶ SVR Index: evaluates SVR as compared to BSI

Swan Ganz VIP catheter

- ▶ Thermodilution catheter
 - Inject temperature measured fluid and calculate CO, CI, SVR, and SVRI off of values
- ▶ Floated through a large bore (Cordis) central line
 - Subclavian or Internal Jugular (RIJ most common)
- ▶ Tip sits in pulmonary artery

Swan-Ganz VIP Catheter

- ▶ Yellow, 110cm in length, marked in 10cm increments
- ▶ Multiple-pressure measure points
 - CVP
 - Right atrial and ventricular pressures
 - Pulmonary Artery Pressures
 - Invasive body Temperature
- ▶ Four to Five Lumens
- ▶ Thermistor for measuring temperature

Transport the Swan Ganz


- ▶ Recognition
- ▶ Note depth and secure so it does not move or migrate deeper
- ▶ Transduce: establish a have a waveform
- ▶ Make sure it is NOT in "wedge"
 - Pull syringe to vacuum and lock off

Hazards of the Swan Ganz

- ▶ Irritates the heart
- ▶ Too deep or balloon inflated too long:
 - Pulmonary embolism
- ▶ Obstruction and/or irritation of smaller blood vessels

Venous Oxygen Saturation

- ▶ Obtain from PA catheter
- ▶ Assesses tissue oxygenation
 - Reflects how well tissue is "taking up" oxygen
- ▶ "Normal" is 75%
 - SaO₂ is 96 to 99%
 - Body uses about 25% of the O₂ available
- ▶ Increased O₂ consumption: pain, agitation, fever, vasopressor medications
- ▶ Decreased O₂ consumption: hypothermia, assisted ventilations, narcotics



Pressure line setup

Components of Pressure System

- ▶ Monitor
- ▶ Low Compliance Tubing
 - More rigid for reducing interference
- ▶ Transducer: interfaces the tubing with the monitor
- ▶ Fast flush
- ▶ Stopcock
- ▶ Pressure bag and fluid

Components of Pressure System


- ▶ Monitor:
 - Cable adapted to transducer
 - Transport monitors include Zoll CCT, Lifepak 12, Propaq, Phillips
 - Must be configured; may have specific cables by manufacturer
 - Should be able to label waveform



Transducer

- ▶ "A substance or device, such as a piezoelectric crystal, microphone, or photoelectric cell, that converts input energy of one form into output energy of another."
 - From Latin *trānsdūcere*, to transfer : *trāns-*, *trans-* + *dūcere*, to lead.
- ▶ From Answers.com
 - <http://www.answers.com/topic/transducer>

Transducer



Setup

- ▶ Tubing
- ▶ Isotonic Fluid:
 - Normal Saline
- ▶ Pressure bag for fluid size
 - 500ml usual
 - Trauma infusers usually for 1000ml
- ▶ Site appropriate
 - Arterial, CVP, ICP, etc.

Set up

- ▶ Tubing flushed: observe flush out of each port
- ▶ Pressure bag inflated to 300mmHg
 - Applies continuous pressure 3 to 6 microdrops per minute
- ▶ Leveled Phlebostatic Axis
- ▶ Labeled in Monitor and Connected
- ▶ Zero monitor

Tubing



Differences

- | | |
|--|--|
| <ul style="list-style-type: none"> ▶ Standard Tubing <ul style="list-style-type: none"> ◦ Flexible ◦ Ports may "Y" in or stopcock ◦ Bore size differs with make, purpose <ul style="list-style-type: none"> ▪ Blood tubing ◦ Gravity flushes | <ul style="list-style-type: none"> ▶ Monitor Tubing <ul style="list-style-type: none"> ◦ Stiffer to touch ◦ "In line" requirements <ul style="list-style-type: none"> ▪ May use stopcocks ◦ Small bore ◦ Transducer has a pig tail for flushing ◦ Setup requires diligent flushing of air |
|--|--|

Pressure Bag and Flush

- | | |
|---|--|
| <ul style="list-style-type: none"> ▶ Inflate to 300mmHg ▶ Most bags us a green marking or visible indicator ▶ Applies a constant pressure to infuse 3 to 6 minidrops per minute ▶ Essential to reduce risk for clot | <ul style="list-style-type: none"> ▶ Flush by pulling pigtail |
|---|--|

Phlebostatic Axis

- ▶ Midchest position; approximate location of aorta and left ventricle
- ▶ Midway point from the anterior and posterior surfaces under the Angle of Louis
- ▶ Key is consistency in transfer of care
 - Zero monitors based on what was previously used
 - OR account for variation (high or low)



Phlebostatic Axis
Using a level, a little high



Phlebostatic axis
A little better

ence lines: (1) a line in out to the side of the a. B. The phlebostatic at the level with this level

Zero Referencing

- ▶ Eliminates the effect of atmospheric pressure on the system
 - Atmospheric pressure: 760mmHg
 - Open system to air
- ▶ Eliminate hydrostatic pressure on system
 - Level to phlebostatic axis
 - Transducer placed at approximate level of the catheter tip within the body

Zero Monitor

- ▶ Transducer stopcock
 - "OFF" to patient
 - "OPEN" to air
- ▶ "ZERO" from monitor menu



Connections




Labels



Flush

- ▶ Pulling red pigtail creates fast flush
 - clear system of air prior to connection to patient
 - Creates the “dynamic response” test to clear line of blood once connected



Technique

- ▶ Consistency from shift to shift and in transfer
 - Reassess and zero at handoff if possible
- ▶ In transport, match as close as practical
 - Tape transducer to patient if possible
 - Stretcher
- ▶ Account for this as potential variable

Problems of leveling

- ▶ Transducer below axis
 - Pressure increased over true pressure
- ▶ Transducer above axis
 - Pressure decreased below true pressure
- ▶ Factor: about 1 inch equals 2mmHg in pressure variant

Troubleshooting

- ▶ CHECK THE PATIENT FIRST
- ▶ Change in clinical condition may manifest in waveform change prior to outward physical change
 - Tension pneumothorax:
 - Hypotension
 - Excessive PEEP
- ▶ In transport patient may be sedated and not complain

Troubleshooting Pressure Systems

- | | |
|--|---|
| <ul style="list-style-type: none"> ▶ No waveform ▶ Artifact: | <ul style="list-style-type: none"> ▶ Check monitor, power, pressure range, connected to proper line (CVP versus ABP), kinked tubing, loose tubing, aspirate blood ▶ Electrical interference, patient movement, tubing movement or vibration |
|--|---|

Problem

Solution

Troubleshooting


- | | |
|---|--|
| <ul style="list-style-type: none"> ▶ Unable to flush line ▶ Reading too high ▶ Reading too low | <ul style="list-style-type: none"> ▶ Check for kinks, pressure bag inflated to 300mmHg, stopcocks turned off ▶ Level, flush, check for occlusion ▶ Level, flush, air bubbles, blood, or other |
|---|--|

Problem

Solution


Troubleshooting

- ▶ Overdamping
 - Waveform blunted
 - Sine like or slurred appearance
 - False low systolic
 - False high diastolic
- ▶ Patient: clinical conditions that may cause this?
- ▶ Equipment issues?




Troubleshooting

- ▶ Underdamping
 - Waveform artifact
 - Sharp, spiked appear
 - False high systolic
 - False low diastolic
- ▶ Patient: clinical conditions that may cause this?
- ▶ Equipment issues



Dynamic Response/Square Wave Test



Medications

- ▶ Potent vasoactive medications benefit from invasive monitoring
- ▶ Highly concentrated meds require central venous access for administration
- ▶ Multiple medications require compatibility checks

Vasoactive Continuous Infusions

- | | |
|--|--|
| <ul style="list-style-type: none"> ▶ Nitroglycerin ▶ Nitroprusside ▶ Esmolol ▶ Labetelol | <ul style="list-style-type: none"> ▶ Epinephrine ▶ Norepinephrine ▶ Milrinone ▶ Vasopressin ▶ Dopamine ▶ Dobutamine ▶ Phenylephrine |
|--|--|

Decrease BP and HR

Increase BP and HR

Decrease BP: Nitrates

- ▶ Nitroglycerin: vasodilator, hits preload
 - Acute Coronary Syndrome
- ▶ Nitroprusside: vasodilator, balanced in reducing preload and afterload
 - Systemic hypertension/hypertensive crisis
 - Acute CVA
 - (not in ACS due to coronary steal: shunts coronary blood flow away myocardium)

Nitroglycerin

- ▶ ACS Standard for angina, chest pain from STEMI
- ▶ Vasodilator
 - Venous smooth muscle relaxer, decrease preload
 - Coronary vasodilation
- ▶ Glass bottle: 50mg/250ml D5W
- ▶ Dosing 5mcg/min to max of 200mcg/min
 - Hint: if at 100mcg/min, try another drug

Decrease BP: Beta blockers

- ▶ Esmolol: (Brevibloc)
 - Short acting Beta 1 selective blocker
 - Potent
 - Manage hypertensive crisis, reduced shear in dissection of aortic aneurysm
- ▶ Labetalol
 - Nonselective Beta with some Alpha 1
 - Reduce myocardial contractility
 - Vasodilation
 - Hypertensive crisis, dissection of aneurysm
 - Bolus or continuous
 - Slower onset, longer acting

Increase BP

- ▶ Epinephrine: Adrenalin
- ▶ Norepinephrine: Levophed
- ▶ Milrinone
 - Phosphodiesterase inhibitor
 - Positive Inotrope and vasodilator
 - Pulmonary Hypertension
- ▶ Vasopressin (100 units/100ml D5W)
 - Vasoconstrictor
 - 0.01 to 0.04 units/min IV

Increase BP

- ▶ Dopamine:
 - Low dose: increases renal blood flow
 - less than 3mcg/kg/min
 - Medium dose: increase myocardial contractility and heart rate
 - 3 to 10mcg/kg/min
 - Higher dosing: generalized vasoconstriction
 - Greater than 10mcg/kg/min

Increase BP

- ▶ Dobutamine
 - Specific Beta1 adrenergic, increase myocardial contractility
 - Used in Acute heart failure, does not cause vasoconstriction
 - Home dobutamine used as bridge to transplant or device

Increase BP

- ▶ Phenylephrine: Neo-synephrine
 - Alpha 1
 - Systemic arterial vasoconstriction
 - Often last ditch for vascular failure in shock
 - Drug induced hypotension: beta blocker overdose

Epinephrine

- ▶ ACLS standard
 - Alpha1 and Alpha2: Vasoconstriction
 - Beta1: Cardiac stimulant, coronary vasodilation
 - Beta2: Bronchodilation
- ▶ Infusion:
 - 2mg or 4mg in 250ml D5W in central line
 - 1 mg/250ml for 4mcg/ml concentration peripheral
 - Dosing: 1 to 2 mcg/min or 0.02 to 0.1mcg/kg/min

Norepinephrine

- ▶ Levophed
- ▶ Systemic vasoconstriction
 - Alpha1 (more) and Beta1 effects
- ▶ Used in shock states
 - Drug of choice for sepsis
- ▶ Infusion: 2mg in 250ml D5W
 - 8 to 12 mcg/min or 0.02 to 0.1mcg/kg/min

Conclusions

- ▶ Recognize the types and presentations of hemodynamic monitoring
 - Basic waveforms
 - Patient Types
- ▶ Understand the key safety factors in the transport of these patients
- ▶ Review basic setup of monitor systems

Sources:

- ▶ www.icufaqs.org
- ▶ www.pacep.org
- ▶ Corbett, J. V. (2008). *Laboratory Tests and Diagnostic Procedures with Nursing Diagnoses* (7th ed.). Upper Saddle River, New Jersey: Pearson/Prentice Hall.
- ▶ Czarnecki, M. (2002). *Critical Care Transport Field Guide*. Sudbury, Massachusetts: Jones and Bartlett.
- ▶ Darovic, G. O. (2002). *Hemodynamic Monitoring: Invasive and Noninvasive Clinical Application* (Third ed.). Philadelphia, Pennsylvania: W. B. Saunders Company.
- ▶ Lehne, R. A. (2007). *Pharmacology for Nursing Care* (Sixth Edition ed.). St. Louis, Missouri: Saunders Elsevier.
- ▶ Saunders. (2008). *Nursing Drug Handbook 2008*. St. Louis, Missouri: Saunders Elsevier.
- ▶ Wagner, K. D., Johnson, K., & Kidd, P. (2006). *High Acuity Nursing* (Fourth ed.). Upper Saddle River, New Jersey: Pearson/Prentice Hall.